


IPS® Sprue Guide

The IPS® Sprue Guide is used to check the correct sprueing of the objects to be pressed on the investment ring base.



Delivery forms

IPS® Sprue Guide

100 g	1x	598993
200 g	1x	598994
300 g	1x	613780

IPS® UniTray

The IPS® UniTray is a universal firing tray that has been designed to accommodate objects to be fired, or pressed ingots and other auxiliaries on both sides. If the IPS UniTray is used in the ceramic furnace, the enclosed metal pins are suitable to place the restorations properly.



Delivery forms

IPS® UniTray

602231

IPS UniTray	1x
Metal Pins A	4x
Metal Pins B	4x
Metal Pins C	4x